

FITTING INSTRUCTIONS

TOYOTA LANDCRUISER

REVERSE SHACKLE KIT

40 SERIES

REVERSE SHACKLE - FRONT

- 1. Remove shackle to chassis brackets both front and rear
- 2. Fit up RHYNO Reverse Shackle cross-member to front of chassis rail (to front edge)
- 3. Fit RHYNO Reverse Shackle chassis bracket and shackles to rear of front springs.
- 4. Lower chassis to support full weight of vehicle to front springs.
- 5. Position rear shackle bracket so the shackles are approx. 15 degrees biased to the rear of the vehicle.
- Weld or bolt the rear shackle brackets to the chassis.

REVERSE SHACKLE - REAR

1. Fit up RHYNO rear spring shackles to original position. Spacer required to raise body at rear of rear springs.

Please Note:

Do not over tighten rear shackle bolts as this will bend assembly



